



NOTES:

1. ON ALL CURB RETURNS, MARK OFF A POINT 4' FROM THE MIDPOINT OF THE CURB RETURN AT THE FACE OF CURB TOWARDS THE MIDPOINT OF THE DIAGONALLY OPPOSITE CURB RETURN.
2. CONNECT THOSE POINTS TO FORM INSIDE STRIPING.
3. MEASURE OUTSIDE STRIPING 11' ON CENTER OF THE INSIDE STRIPING.
4. AT SIGNALIZED INTERSECTIONS, PED PUSH BUTTONS SHALL BE INSTALLED PER ADA STANDARDS.

(Not To Scale)



**ENGINEERING
DEPARTMENT**

**CROSS WALK STRIPING
ON ARTERIAL STREETS**

John E. Stevenson
JOHN E. STEVENSON CITY ENGINEER

DATE: MAR. 13, 2001
REVISED:

SHEET NO.
ST-28